



**DIVERSIFIED**  
**TESTING LABORATORIES, INC.**  
 WORLDWIDE SERVICE

“We Test Per Your Request”

336 WEST FRONT STREET  
 P.O. BOX 4004  
 BURLINGTON, NORTH CAROLINA 27215  
 PHONE (336) 227-7710 • FAX (336) 227-1175  
 www.diversifiedtestinglabs.com

January 27, 2020

THORLABS LTD.  
 1 Saint Thomas Place  
 Cambridgeshire Business Park  
 Ely, Cambridgeshire CB7 4EX  
 United Kingdom

Reference: Laboratory Test Report  
 Lab Identification No. 39818  
 Invoice No. 71093

One (1) fabric sample, identified as **THORLABS LASER CURTAIN RAW MATERIAL**, was received and tested in accordance with the City of New York Bulletin No. 44 of the Board of Standards and Appeals (Cal. No. 294-40-SR). The results are as follows:

<u>Specimen Number</u>	<u>After Flame</u>		<u>After Glow</u>	
	<u>Length</u>	<u>Width</u>	<u>Length</u>	<u>Width</u>
1	0.0	0.0	0.0	0.0
2	0.0	0.0	0.0	0.0
3	0.0	0.0	0.0	0.0
Avg.	0.0		0.0	

The fabric sample submitted **meets** the minimum requirements of the above standard. No flashing shall occur at any time on the length of the test specimen. The average continuation of flaming shall not exceed three (3) seconds. The average continuation of glow at the edge of the charred area shall not exceed an additional twenty (20) seconds after the cessation of flaming.

If there are any questions or when we can be of further assistance, please let us know.

Sincerely,

Brian S. Dement

BSD/mr

